



## Hi & Bestech company

No. 198, Chung Shan Road, Sec.2, Tantzé,  
Taichung Hsien (42745), Taiwan

TEL:+886-4-25355152

FAX:+886-4-25354775

E-mail: [info@tonerchips.com](mailto:info@tonerchips.com)

## HP 8727/28/6656/57/816/817 Circuitry tester



- Insert cartridge with 30 degree (be careful, not to damage pogo-pins) into the slot tightly (as shown in the picture)
- Push the testing button near to LED display
- For 27/56 cartridges, LED number should be 416. For 28/57 cartridges, LED number should be 300. LED number shown more or less means electrical short or broken.
- Test one cartridge at a time
- Available in 110/220 V
- 6 months warranty



NEW DESIGN on Cradle and Pogo Pins